If you are using a printed copy of this procedure, and not the on-screen version, then you MUST make sure the dates at the bottom of the printed copy and the on-screen version match.

The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ Training Office, Bldg. 911A

C-A OPERATIONS PROCEDURES MANUAL

ATTACHMENT

4.120.22.d AGS Sweep Tests

C-A-OPM Procedures in which this Attachment is used.			
4.120.22			

Hand Processed Changes

HPC No.	<u>Date</u>	Page Nos.	<u>Initials</u>	
	Approved:	· · · · · · · · · · · · · · · · · · ·		
		Collider-Accelerator Depar	tment Chairman	Date

V. Castillo

4.120.22.d AGS Sweep Tests

PASS ANNUAL ACCEPTANCE TEST PROTOCOL

Division A Software Filename and Checksum: Title:	Checksum:
Division B Software Filename and Checksum: Title:	Checksum:
<u>Initial testing complete</u> :	
Test Team Leader's Name (Print):	Life Number:
The A Theory I and Lordy Name (Class).	Data
Test Team Leader's Name (Sign):	Date:/
Acceptance test procedure complete (following repairs and retesting if required):
Test Team Leader's Name (Print):	Life Number
Test Team Leader's Name (Trimt).	Life Number.
Test Team Leader's Name (Sign):	_ Date://
Test results reviewed by:	
Safety Section Head's Name (Print):	Life Number:
Safety Section Head's Name (Sign):	_ Date://
Test results accepted by Radiation Safety Committee:	
RSC Member's Name (Print):	_ Life Number:
RSC Member's Name (Sign):	Date:/

1.1 Test to sweep the AGS

PLACE	AGS in Con. Acs. (CA) from MCR with 693 key and Light /Button	
VERIFY	(L/B) on Y-Panel MCR sees at Y-Panel AGS in	CA
RESET VERIFY VERIFY VERIFY	South Shield Door (SSD) at encl 2921 with 715 key At encl 2921 Reset light is MCR sees at W-Panel SSD Not Reset light is MCR sees at Opto monitor SSD is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	C14 Escape (C14-E) gate at encl 1388 with 715 key At encls 1388, and 1390 (Ring door) Reset light is MCR sees at W-Panel C14-E Not Reset light is MCR sees at Opto monitor C14-E gate is	ON OFF RESET
RESET VERIFY VERIFY	C14 Rest room at encl 1389 with 715 key At encl 1389 and 1390 (Ring door) Reset light is MCR sees at Opto monitor C14 Rest room is	ON RESET
RESET VERIFY VERIFY VERIFY	N322 gate at encl 5031 with 715 key At encl 5031 Reset light is MCR sees at W-Panel N322 gate Not Reset light is MCR sees at Opto monitor N322 gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	AGS / HEBT gate at encl M14A24A3 with 715 key At encl M14A24A3 Reset light is MCR sees at W-Panel AGS / HEBT Not Reset light is MCR sees at Opto monitor AGS / HEBT gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	L19 Alcove at Reset encl with 715 key At Reset encl Reset light is MCR sees at W-Panel L19 Alcove Not Reset light is MCR sees at Opto monitor L19 Alcove is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	Labyrinth A (Laby-A) gate at encl 4525 with 715 key At encl 4525 Reset light is MCR sees at W-Panel Laby-A gate Not Reset light is MCR sees at Opto monitor Laby-A gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	Labyrinth B (Laby-B) gate at encl 4526 with 715 key At encl 4526 Reset light is MCR sees at W-Panel Laby-B gate Not Reset light is MCR sees at Opto monitor Laby-B gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY VERIFY	K7 Escape (K7-E) at encl 1385 with 715 key At encl 1385 Reset light is At encl 1386, at bottom of stair, Reset light is MCR sees at W-Panel K7-E Not Reset light is MCR sees at Opto monitor K7-E gate is	ON ON OFF RESET
RESET VERIFY VERIFY	North Conjunction (NrCon) gate at encl 2921 with 715 key At encl 2921 Reset light is MCR sees at W-Panel NrCon Not Reset light is	ON OFF

VERIFY	MCR sees at Opto monitor NrCon is	RESET
RESET VERIFY VERIFY VERIFY	I4 Alcove at Reset encl with 715 key At Reset encl Reset light is MCR sees at W-Panel I4 Alcove Not Reset light is MCR sees at Opto monitor I4 Alcove is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	North gate at encl 1369 with 715 key At encl 1369 Reset light is MCR sees at W-Panel North gate Not Reset light is MCR sees at Opto monitor North gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	North Shield Door (NSD) at encl 2924 with 715 key At encl 2924 Reset light is MCR sees at W-Panel NSD Not Reset light is MCR sees at Opto monitor NSD is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	F15 Alcove (So Wir. Tnnl. Hatch [SwtH])at encl 1378 with 715 key At encl 1378 Reset light is MCR sees at W-Panel F15 Alcove / SwtH Not Reset light is MCR sees at Opto monitor F15 Alcove / SwtH is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	South gate at encl 1369 with 715 key At encl 1369 Reset light is MCR sees at W-Panel South gate Not Reset light is MCR sees at Opto monitor South gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	No. Wir. Tnnl Terml rm (NwtTr) gate at encl 1395 with 715 key At encl 1395 Reset light is MCR sees at W-Panel NwtTr Not Reset light is MCR sees at Opto monitor NwtTr gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	So. Wir. Tnnl Tgt Bldg (SwtTgt) gate at encl 1392 with 715 key At encl 1392 Reset light is MCR sees at W-Panel SwtTgt gate Not Reset light is MCR sees at Opto monitor SwtTgt gate is	ON OFF RESET
VERIFY VERIFY	At So. Wir. Tnnl Hatch (SwtH) at encl 1379 F15 Alcove is At encl 1379 Reset light is	RESET ON
RESET VERIFY VERIFY VERIFY	So. Wir. Tnnl Power room (SwtPr) gate at encl 1398 with 715 key At encl 1398 Reset light is MCR sees at W-Panel SwtPr gate Not Reset light is MCR sees at Opto monitor SwtPr gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	So. Wir. Tnnl Term room (SwtTr) gate at encl 1395 with 715 key At encl 1395 Reset light is MCR sees at W-Panel SwtTr gate Not Reset light is MCR sees at Opto monitor SwtTr gate is	ON OFF RESET
RESET VERIFY VERIFY VERIFY	FEB2 gate at encl 3343 with 715 key At encl 3343 Reset light is MCR sees at W-Panel FEB2 gate Not Reset light is MCR sees at Opto monitor FEB2 gate is	ON OFF RESET

		VERIFY	MCR sees at Opto Monitor AGS South, North, NrCon, Laby, N322, Swt gates and Lights	ОК
		VERIFY	MCR sees at Opto Monitor AGS Hatches, Alcoves, Shield Doors and FEB2	ОК
		Check for	acceptance of test to Sweep the AGS	
1.2		Test to drop	AGS Sweep	
		VERIFY	MCR sees at Opto Monitor AGS South, North, NrCon, Laby, N322, Swt gates and Lights	ОК
		VERIFY	MCR sees at Opto Monitor AGS Hatches, Alcoves, Shield Doors and FEB2	ОК
		OPEN	Any AGS gate ; Name gate:	
		VERIFY	MCR sees at Opto Monitor AGS South, North, NrCon, Laby, N322, Swt gates and Lights	INTERLOCK
		OPEN	Any AGS Hatch, Shld Door or FEB2; Name:	
		VERIFY	MCR sees at Opto Monitor AGS Hatches, Alcoves, Shield Doors and FEB2	INTERLOCK
☐ Check for acceptance of test to drop AGS Sweep				
END OF TEST PROCEDURE				
TTL:	Sigr	n for completio	on of initial testing:	
			Date://	
TTL:	Sigr	n for completion	on of final testing:	
			Date:/	,